BLUEBOX RFid System

Order CODE	DESCRIPTION	LENGHT (Meter)	R-IN-LF-3122L[3]	R-IN-HF-3122H[3]	R-IN-UHF-3122U[3]	R-IN-LF-5121L	R-IN-LF-5131L	R-IN-HF-5121H	R-IN-HF-5131H	R-IN-UHF-5121U	R-IN-UHF-5131U	R-IN-UHF-LR-4A-232	R-IN-UHF-LR-4A-ET
		PRODUCTS	DESKTOP LF	DESKTOP HF	DESKTOP UHF	BASIC LF		BASIC HF		BASIC UHF			
POWER													
CABLES													
R-IN-AC-0901A	Power cable with M12-A 5PIN (female) connector and open ends	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0919A	Power cable with M12-A 4PIN (female) connector and open ends	2	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0922A	M12-A 5PIN (female) connector with open ends for power and DB9 for RS232/485	3	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR													
R-IN-AC-0910A	M12-A 5PIN (female) connector only with screw connections - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0918A	M12-A 5PIN (female) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0930A	M12-A 4PIN (female) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES													
RS232/485													
R-IN-AC-0903A	RS232/485 cable with M12-A 8PIN (female) with DB9 for RS232 and open ends for RS485	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0904A	RS232/485 cable with M12-A 8PIN (female) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0914A	M12-A 8PIN (female) connector only with screw connections for RS232/485 - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
ETH													
R-IN-AC-0902A	ETH cable with M12-D (male) and RJ45, DYNAMIC installation	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0913A	M12-D 4PIN (male) connector only with screw connections for Ethernet - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0916A	M12-D 4PIN (male) connector only with screw connections for Ethernet - Plastic SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0921A	ETH cable with M12-D (male) and RJ45, FIXED installation	20	-	-	-	-	-	-	-	-	-	-	-
PROFIBUS													
R-IN-AC-0906A	Profibus termination resistance with M12-B 4 PIN (male)	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0907A	Profibus "T" connector with 3 M12-B 4PIN (1 Male - 2 Female)	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0908A	PROFIBUS cable with M12-B (male) and M12-B (female)	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0912A	M12-B 4PIN (male) connector only with screw connections for profibus - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
I/O													
R-IN-AC-0905A	I/O cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0911A	M12-A 5PIN (male) connector only with screw connections for advant I/O - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0917A	M12-A 5PIN (male) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0920A	I/O cable with M12-A 12PIN (male)	4	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0931A	M12-A 12PIN (male) connector only with solder connections - PLASTIC SHELL -		-	-	-	-	-	-	-	-	-	-	-
USB													
R-IN-AC-0909A	USB interface with M12-USB-MINI and USB A connector	1	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0928A	USB cable A (male) - B (male)	1,8	X	X	X	-	-	-	-	-	-	-	-
R-IN-AC-0929A	USB mini cable A (male) - B 5p MINI usb	1,5	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation													
R-IN-AC-0905A	Cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
CAPS													
R-IN-AC-0915A	Plastic cap for M12 female connectors	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0923A	TNC cap for female connectors	-	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-0924A	Cable housing IP67 for ETH connections with RJ45	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0925A	Plastic cap IP67 for RJF544 connector	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0926A	Platic cap for M12 usb connector	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS													
R-IN-AC-9951U	TNC (female) – TNC (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9952U	TNC (male) 50 Ohm terminator	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9953U	TNC (female) – N (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9954U	TNC (male) – SMA (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9955U	TNC (female) - TNC (male) right angle adapter	-	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-9957U	SMA (male) - SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9958U	Panel TNC (female) - ufl (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9959U	TNC (female) – SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS													
R-IN-AC-9903U	Antenna cable withTNC (male) and TNC (male)	3	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-9904U	Antenna cable withTNC (male) and TNC (male)	6	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-9906U	Antenna cable withTNC (male) and TNC (male)	10	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-9907U	Antenna cable withTNC (male) and TNC (male)	15	-	-	-	-	-	-	-	-	X	-	-
R-IN-AC-9908U	Antenna cable withTNC (male) and TNC (male)	25	-	-	-	-	-	-	-	-	X	-	-
POWER SUPPLY													
R-IN-AC-0951A	Power Supply AC - DC 15W 5 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0958A	Power Supply AC - DC 15W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0959A	Power Supply AC - DC 35W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0960A	Power Supply AC - DC 50W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0965A	Power Supply AC - DC 35W 15 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0971A	Power Supply AC - DC 35W 24 Vdc OUT	-	-	-	-	X	X	X	X	X	X	-	-
R-IN-AC-0972A	Power Supply AC - DC 50W 24 Vdc OUT	-	-	-	-	X	X	X	X	X	X	-	-
R-IN-AC-0990A	Power Supply 24V 35W with box BB	-	-	-	-	X	X	X	X	X	X	-	-
R-IN-AC-0991A	Power Supply 24V 25W with M12-A-5PIN (female) Wall mount adaptor - European 2P	1,8	-	-	-	-	-	-	-	-	-	-	-
SUPPORTS													
R-IN-AC-9921U	Mounting kit for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9922U	Munting kit for Antennas 9128U & 9129U	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9923U	Foldind stand for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9924U	Adjustable stand for CX-E / CX-EL readers	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9925U	Adapter 9924U/9126U	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9926U	Adjustable stand for CX-E / CX-EL readers / 9126U	-	-	-	-	-	-	-	-	-	-	-	-

Order CODE	R-IN-LF-5221L	R-IN-LF-5222L	R-IN-LF-5223L	R-IN-LF-5231L	R-IN-LF-5232L	R-IN-LF-5233L	R-IN-LF-5241L	R-IN-LF-5242L	R-IN-LF-5243L	R-IN-HF-5221H	R-IN-HF-5222H	R-IN-HF-5223H	R-IN-HF-5231H	R-IN-HF-5232H	R-IN-HF-5233H	R-IN-HF-5241H	R-IN-HF-5242H	R-IN-HF-5243H	R-IN-HF-5231HM	R-IN-HF-5232HM	R-IN-HF-5233HM	R-IN-UHF-5221U	R-IN-UHF-5222U	R-IN-UHF-5223U	R-IN-UHF-5231U	R-IN-UHF-5232U	R-IN-UHF-5233U	R-IN-UHF-5237U	R-IN-UHF-5238U	R-IN-UHF-5239U
	ADVANT LF									ADVANT HF									ADVANT HF MR			ADVANT UHF								
POWER																														
CABLES																														
R-IN-AC-0901A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0919A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0922A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR																														
R-IN-AC-0910A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0918A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0930A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																														
RS232/485																														
R-IN-AC-0903A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
R-IN-AC-0904A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
R-IN-AC-0914A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
ETH																														
R-IN-AC-0902A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
R-IN-AC-0913A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
R-IN-AC-0916A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
R-IN-AC-0921A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
PROFIBUS																														
R-IN-AC-0906A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
R-IN-AC-0907A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
R-IN-AC-0908A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
R-IN-AC-0912A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
I/O																														
R-IN-AC-0905A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
R-IN-AC-0911A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
R-IN-AC-0917A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
R-IN-AC-0920A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0931A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
USB																														
R-IN-AC-0909A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0928A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0929A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
TTL / Mag.Stripe Emulation																														
R-IN-AC-0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																														
R-IN-AC-0915A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0923A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-0924A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0925A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0926A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
ADAPTERS																														
R-IN-AC-9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9952U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	-	-	-
R-IN-AC-9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9954U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9955U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																														
R-IN-AC-9903U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-9904U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-9906U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-9907U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-9908U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
POWER SUPPLY																														
R-IN-AC-0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0959A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0960A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0965A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0971A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0972A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0990A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0991A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
SUPPORTS																														
R-IN-AC-9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9924U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9926U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Order CODE	R-IN-LF-5224L	R-IN-LF-5225L	R-IN-LF-5227L	R-IN-LF-5228L	R-IN-HF-5224H	R-IN-HF-5225H	R-IN-HF-5227H	R-IN-HF-5228H	R-IN-UHF-5224U	R-IN-UHF-5225U	R-IN-UHF-5325U	R-IN-UHF-5325U-RTC	R-IN-UHF-5335U	R-IN-UHF-5335U-RTC	R-IN-UHF-5345U	R-IN-UHF-5345U-RTC	R-IN-UHF-5326U	R-IN-UHF-5326U-RTC	R-IN-UHF-5336U	R-IN-UHF-5336U-RTC	R-IN-UHF-5346U	R-IN-UHF-5346U-RTC
	M30 reader LF				M30 reader HF				M30 reader UHF		CX Ethernet with RJ45						CX Ethernet with M12					
POWER																						
CABLES																						
R-IN-AC-0901A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0919A	X	X	-	-	X	X	-	-	X	X	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0922A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
CONNECTOR																						
R-IN-AC-0910A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0918A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0930A	X	X	-	-	X	X	-	-	X	X	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																						
RS232/485																						
R-IN-AC-0903A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0904A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0914A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ETH																						
R-IN-AC-0902A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-0913A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-0916A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
R-IN-AC-0921A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
PROFIBUS																						
R-IN-AC-0906A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0907A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0908A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0912A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I/O																						
R-IN-AC-0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0911A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0917A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0920A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0931A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
USB																						
R-IN-AC-0909A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0928A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0929A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation																						
R-IN-AC-0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																						
R-IN-AC-0915A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0923A	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-0924A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	-	-	-	-	-	-
R-IN-AC-0925A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	-	-	-	-	-	-
R-IN-AC-0926A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS																						
R-IN-AC-9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9952U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	X	X
R-IN-AC-9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9954U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9955U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																						
R-IN-AC-9903U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-9904U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-9906U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-9907U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
R-IN-AC-9908U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
POWER SUPPLY																						
R-IN-AC-0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0959A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0960A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0965A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0971A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0972A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0990A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
R-IN-AC-0991A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
SUPPORTS																						
R-IN-AC-9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9924U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9926U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Order CODE	R-IN-UHF-5426U-G	R-IN-UHF-5426U-RTC-G	R-IN-UHF-5427U-G	R-IN-UHF-5426U-G-FCC	R-IN-UHF-5426U-RTC-G-FCC	R-IN-UHF-5427U-G-FCC	R-IN-UHF-5526U-G	R-IN-UHF-5526U-RTC-G	R-IN-UHF-5527U-G	R-IN-UHF-5526U-G-FCC	R-IN-UHF-5526U-RTC-G-FCC	R-IN-UHF-5527U-G-FCC	R-IN-UHF-9123U	R-IN-UHF-9124U	R-IN-UHF-9125U	R-IN-UHF-9126U	R-IN-UHF-9127U	R-IN-UHF-9131U	R-IN-UHF-9132U	R-IN-UHF-9133U	R-IN-UHF-9134U	R-IN-UHF-9128U	R-IN-UHF-9129U
	CX-AVI ETSI			CX-AVI FCC			CX-AVI LR						Antennas										
POWER																							
CABLES																							
R-IN-AC-0901A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0919A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0922A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR																							
R-IN-AC-0910A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0918A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0930A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																							
RS232/485																							
R-IN-AC-0903A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0904A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0914A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ETH																							
R-IN-AC-0902A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0913A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0916A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0921A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
PROFIBUS																							
R-IN-AC-0906A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0907A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0908A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0912A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I/O																							
R-IN-AC-0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0911A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0917A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0920A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0931A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
USB																							
R-IN-AC-0909A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0928A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0929A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation																							
R-IN-AC-0905A	-	-	X	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																							
R-IN-AC-0915A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0923A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0924A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0925A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0926A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS																							
R-IN-AC-9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9952U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X
R-IN-AC-9954U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9955U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	-	-
R-IN-AC-9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																							
R-IN-AC-9903U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X[2]	X[2]
R-IN-AC-9904U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X[2]	X[2]
R-IN-AC-9906U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X[2]	X[2]
R-IN-AC-9907U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X[2]	X[2]
R-IN-AC-9908U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X[2]	X[2]
POWER SUPPLY																							
R-IN-AC-0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0959A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0960A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0965A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0971A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0972A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0990A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
R-IN-AC-0991A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-
SUPPORTS																							
R-IN-AC-9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
R-IN-AC-9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X
R-IN-AC-9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
R-IN-AC-9924U	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	X[4]	X[4]	-	-	-	-	-	-
R-IN-AC-9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
R-IN-AC-9926U	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	X	X	-	-	-	-	-	-

X[1] with the addition of 9954U
X[2] with the addition of 9953U
X[3] USB cable included
X[4] with the addition of 9925U