



order CODE	DESCRIPTION	LENGHT (Meter)	DESKTOP			BASIC			ADVANT				M30 reader			CX		CX-E		CX-EL		ANTENNA				
			LF	HF	UHF	LF	HF	UHF	LF	HF	HF MR	UHF	LF	HF	UHF	eth with RJ45	eth with M12	ETS1	FCC	ETS1	FCC	SMA	TNC	N		
POWER																										
CABLES																										
0901A	Power cable with M12-A 5PIN (female) connector and open ends	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0919A	Power cable with M12-A 4PIN (female) connector and open ends	2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0922A	M12-A 5PIN (female) connector with open ends for power and DB9 for RS232/485	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
CONNECTOR																										
0910A	M12-A 5PIN (female) connector only with screw connections - METAL SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0918A	M12-A 5PIN (female) connector only with screw connections - PLASTIC SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0930A	M12-A 4PIN (female) connector only with screw connections - PLASTIC SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
INTERFACE CABLES																										
RS232/485																										
0903A	RS232/485 cable with M12-A 8PIN (female) with DB9 for RS232 and open ends for RS485	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0904A	RS232/485 cable with M12-A 8PIN (female) and open ends M12-A 8PIN (female) connector only with screw connections for RS232/485 - METAL SHELL	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0914A	M12-A 8PIN (female) connector only with screw connections for RS232/485 - METAL SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
ETH																										
0902A	ETH cable with M12-D (male) and RJ45, DYNAMIC installation M12-D 4PIN (male) connector only with screw connections for Ethernet - METAL SHELL	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0913A	M12-D 4PIN (male) connector only with screw connections for Ethernet - METAL SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0916A	M12-D 4PIN (male) connector only with screw connections for Ethernet - PLASTIC SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0921A	ETH cable with M12-D (male) and RJ45, FIXED installation	20	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
PROFIBUS																										
0906A	Profibus termination resistance with M12-B 4 PIN (male)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0907A	Profibus "T" connector with 3 M12-B 4PIN (1 Male - 2 Female)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0908A	PROFIBUS cable with M12-B (male) and M12-B (female)	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0912A	M12-B 4PIN (male) connector only with screw connections for profibus - METAL SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
I/O																										
0905A	I/O cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0911A	M12-A 5PIN (male) connector only with screw connections for advant I/O - METAL SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0917A	M12-A 5PIN (male) connector only with screw connections - PLASTIC SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0920A	I/O cable with M12-A 12PIN (male)	4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0931A	M12-A 12PIN (male) connector only with solder connections - PLASTIC SHELL	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
USB																										
0909A	USB interface with M12-USB-MINI and USB A connector	1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0928A	USB cable A (male) - B (male)	1,8	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0929A	USB mini cable A (male) - B 5p MINI usb	1,5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
TTL / Mag.Stripe Emulation																										
0905A	Cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
CAPS																										
0915A	Plastic cap for M12 female connectors	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0923A	TNC cap for female connectors	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0924A	Cable housing IP67 for ETH connections with RJ45	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0925A	Plastic cap IP67 for RJF544 connector	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0926A	Plastic cap for M12 usb connector	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
ADAPTERS																										
9951U	TNC (female) - TNC (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9952U	TNC (male) 50 Ohm terminator	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9953U	TNC (female) - N (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9954U	TNC (male) - SMA (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9955U	TNC (female) - TNC (male) right angle adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9957U	SMA (male) - SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9958U	Panel TNC (female) - ufl (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9959U	TNC (female) - SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
CABLE EXTENSIONS																										
9903U	Antenna cable withTNC (male) and TNC (male)	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9904U	Antenna cable withTNC (male) and TNC (male)	6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9906U	Antenna cable withTNC (male) and TNC (male)	10	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9907U	Antenna cable withTNC (male) and TNC (male)	15	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9908U	Antenna cable withTNC (male) and TNC (male)	25	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
POWER SUPPLY																										
0951A	Power Supply AC - DC 15W 5 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0958A	Power Supply AC - DC 15W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0959A	Power Supply AC - DC 35W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0960A	Power Supply AC - DC 50W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0965A	Power Supply AC - DC 35W 15 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0971A	Power Supply AC - DC 35W 24 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0972A	Power Supply AC - DC 50W 24 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0990A	Power Supply 24V 35W with box 8B	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
0991A	Power Supply 24V 25W with M12-A-5PIN (female) Wall mount adaptor - European 2P	1,8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
SUPPORTS																										
9921U	Mounting kit for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9922U	Munting kit for Antennas 9128U & 9129U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9923U	Foldind stand for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9924U	Adjustable stand for CX-E / CX-EL readers	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9925U	Adapter 9924U/9126U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
9926U	Adjustable stand for CX-E / CX-EL readers / 9126U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

X¹ with the addition of 9954U
X² with the addition of 9953U
X³ USB cable included
X⁴ with the addition of 9925U